



**Service wrench provided
'Tighten when leaking?'**

Thom Roy—Fremont Building Inspector



When CSST is used
Manufacturer's nail plate is required

Thom Roy—Fremont Building Inspector



**Proper nail plates required at
penetration of framing members
for top and bottom plates**

Thom Roy—Fremont Building Inspector



Take care of this *before*
you call for inspection

Thom Roy—Fremont Building Inspector



**Gas manifold for distribution
with shut-offs for each branch line**

Thom Roy—Fremont Building Inspector



Not a good situation!

Thom Roy—Fremont Building Inspector



Thom Roy—Fremont Building Inspector



Whoops?

Plates need to be supported with framing member—plates need to be continuous!

Thom Roy—Fremont Building Inspector



Not “preferred” method
for routing and securing CSST

Thom Roy—Fremont Building Inspector



**Protective sleeves are stripped back too far!
Unnecessary kinks!**

Thom Roy—Fremont Building Inspector



-Garages-
**Stairways require proper
handrails and guards**

Thom Roy—Fremont Building Inspector



Foundation
Sealed, stone & pipe drainage
with protective fabric

Thom Roy—Fremont Building Inspector



Almost?

Thom Roy—Fremont Building Inspector



Foundation wall penetration.
Requires sleeve and fernco coupling.

Thom Roy—Fremont Building Inspector



If 18" of clearances is the minimum?

Than is 16" ok?

Noop

Thom Roy—Fremont Building Inspector